Eclipse DOT

Eclipse DOT

Vehicle Inspection

Eclipse DOT, Covering all of low

Form

	Front of Vehicle			Side Of Vehicle			Front of Trailer	
٦	Vehicle Level Light Lens Condition Puddles / Leaks			Door Mirror Light Lens Condition		ſ	Light Lens Condition Reflectors Side of Trailer	
Front and Engine Compartment Inspection	Engine Compartmen Coolant Level Alternator Water Pump Rim			Drive Train Exhaust Frame Drive Shaft Fuel			Light Lens Condition Reflectors Landing Gear Frame Rim	
	Hub Oil Lug Nuts Rim Condition Tire			Tanks Secured Leaks Fuel Cap Tight Rim			Hub Oil Lug Nuts Rim Condition Tire	
	Condition Inflation Tread Depth (4/32") Brake			Hub Oil Lug Nuts Rim Condition Tire		pectíon	Condition Inflation Tread Depth (2/32") Spacing	
	Air Lines Brake Chamber Slack Adjuster (1") Shoes / Pads (1/4") Drum / Rotor Steering	Side Of Vehicle Inspection	Condition Inflation Tread Depth (2/32") Spacing Brake Air Lines	10 000 000 100 Trailer Inspection	Trailer Ins	Brake Air Lines Brake Chamber Slack Adjuster (< 1") Shoes / Pads (> 1/4") Drum / Rotor		
	Pitman Arm Steering Box Hoses Suspension Front Spring Hanger Rear Spring Hanger Spring Condition			Brake Chamber Slack Adjuster (1") Shoes / Pads (1/4") Drum / Rotor Suspension Front Spring Hanger Rear Spring Hanger Spring Condition			Front Spring Hanger Rear Spring Hanger Spring Condition U Bolts Air Bags Air Bag Mounts Shock Absorber Rear of Trailer	
	U Bolts Shock Absorber Engine Engine Engine Oil Power Steering Air Compressor Hoses			U Bolts Air Bags Air Bag Mounts Shock Absorber Rear of Truck Mud Flaps Light Lens Condition Reflectors Tailgate / Doors		Acc	Mud Flaps Light Lens Condition Reflectors Tailgate / Doors	



FIFT		
Sth Wheel Coupling Truck Side Air Connect Electrical Connect Air Line Condition Trailer Side Air Connect Electric line condition Trailer Side Air Connect Electrical Connect Mounting Mounting Mounting Bolts Lock Dogs Release Lever Sth Wheel Platform Skid Plate Gap Trailer King Pin Lock Jaws Apron	Side of Truck Clearance 4 Ways Rear of Truck Left Turn Right Turn Right Turn Right Turn	ABS Left Turn Right Turn 4 Ways High Beam Glass Mirrors Windshield Wipers / Washers Start Safe Start Air Pressure Gauge Voltammeter
Pintle Hitch coupling Truck Side Air Connect Electrical Connect Air Line Condition Electric line condition Trailer Side Air Connect Electrical Connect Tractor Pintle Hitch Mounting Bolts Locking Lever Safety Devices Trailer Pintle Hitch Mounting Bolts Safety Devices Trailer Pintle Hitch Trailer Toung Storage Compartment	Right Turn 4 Ways Clearance Rear of Trailer Left Turn Right Turn 4 Ways Brake Clearance / Tail Passenger Vehicle Emergency Exits (4) Seating Steps Hand Rail Lights Lift	Water Temp Gauge Oil Pressure Gauge Climate Control Heater Defroster Brake Test Tug Test (parking) Service Brake Air Brake Test Compressor Check 85-100psi under 45 sec. Cuts out at 125psi System Leaks - < 4 psi loss in 1 min *A < 3 psi loss in 1 min *B Low Air Alarm - 60psi alarm sounds Brake Set - 20-40psi Brakes Set